

Charlotte NC homeowner guide

Refrigerator

Not cooling enough	Dirty condenser coils (clean first), evaporator fan, or compressor.
Ice maker not working	Clogged water filter (replace first), frozen fill tube, or assembly failure.
Frost in freezer	Defrost heater or defrost thermostat failure.
Running constantly	Condenser coils, door gasket wear, or refrigerant issue.

Washing machine

Clothes still wet after cycle	Lid switch, drive belt, or drain pump failure.
Musty smell persists	Mold in door gasket folds or drum bearing housing.
Not draining	Clogged pump filter or drain pump failure.
Banging during spin	Drum bearing wear or foreign object in drum.

Dryer

Two cycles to dry	Blocked vent hose, failing heating element, or full lint trap.
No heat	Blown thermal fuse (usually caused by blocked vent) or element failure.
Squealing noise	Worn drum seal or idler pulley.

Oven / range

Gas burner won't light	Igniter wear -- most common repair on ranges over 5 years.
Uneven baking	Failing bake element or temperature sensor.

Dishwasher

Standing water after cycle	Clean the filter first. If persists: drain pump failure.
Dishes still dirty	Clogged spray arms or pump issue.

Just Call Appliance Repair covers Charlotte, Huntersville, Concord, Matthews, and Mint Hill.